



# Classic 1m Steplift

Reliable and cost  
effective lift for up to  
one metre of travel



A functional and robust design for domestic and public access



- 280kg capacity \*
- up to 1m travel
- access between 2 levels
- user plus attendant
- wheelchair or ambulant
- internal & external
- domestic & public access

**The Classic 1m Steplift boasts a small footprint along with an increased load capacity - now capable of lifting 280kg to a maximum of 1m between two floors.**

With increased clear access, the hydraulically driven, scissor based platform is suitable for both internal and external environments.

Functional yet stylish the Classic 1m Steplift moves quietly between levels to provide safe and reliable access in public buildings and for the home. Further key features include an on-board drive and mechanical on-board ramp.

As with all Pollock Lifts, the Classic has exceptional safety standards, exceeding requirements in many areas.

## 12 Months Warranty

Our Classic 1m Steplift comes with 12 months Parts and Labour as standard. We also offer Extended Warranties up to 5 years covering you for all service and maintenance costs.



features  
unique  
to pollock  
Lifts

raising expectations with the most advanced technology



**Above from left to right:**

Through Entry configuration with fixed ramp at lower level

Bridging Steps configuration with on-board ramp

Pit Mounted configuration

## Designed to last

The Classic is designed to be robust and hard wearing and is therefore an ideal option for external public use. With the pump unit integrated within the lift it offers **reduced vandalism risk** and no need for a separate control unit location.

Taking only **one day to install** with **minimal builders work**, the lift can also be **relocated** offering great flexibility for the future.

**Low maintenance** requirements and **easy access to the pump** for servicing means your Classic 1m Steplift will provide reliable and efficient access for many years to come.

## Why choose Pollock Lifts?

We have been specialising in lift access since 1983 and really understand our customers' needs and concerns.

When mobility access is required it raises many important questions and practical issues that our team are experts at solving. And our highly trained support team are here 24 hours a day to respond to your needs, wherever you are located.

As leaders in state-of-the-art lift technology, our versatile range of access solutions are designed to be elegant and fit easily into your environment, freeing up space and ensuring the ultimate in comfort and safety for its users.

“ The service we received from Pollock Lifts was second-to-none. We would highly recommend their range of access lifts and their experienced team to offer the best advice. ”



## Standard Features

### Compact design

- Stylish protective bellows - rigid and durable
- Aluminium checker plate flooring
- Simple to use - single rocker switch control
- Lower onboard ramp
- Easy to use emergency lowering system
- Improved IP 67 rated switching (waterproof)

### Integrated pump unit

- Reduced vandalism risk
- No separate control or pump location

### Easy installation and service access

- 1 day installation - minimal builders work
- Low maintenance
- Can be relocated

## Optional Features

### Gate

- Manual lower gate
- Lower fixed ramp

### Controls

- Autodialler
- Alarm
- Keyswitch
- Isolation switch
- Remote controls
- Full controls on board and at serviced floors
- Remote painted aluminium call posts

## Choose from:

**2 Models**

- Domestic
- Public Access (on-board gate)

**3 Configurations**

- Through Entry
- Bridging Steps (800 x 1400mm only)
- Pit Mounted (no ramp)

**3 Platform Sizes**

- 800 x 1400mm
- 900 x 1400mm
- 1100 x 1400mm

**3 Finish Options**

- Handrails
- Silicon acrylic clear infill panels †
- Aluminium infill panels †
- Custom colour

† Image, above centre, shows a split view of the two infill options.

Exceptional  
safety and  
load capacity  
unique\* to  
Pollock Lifts



## Technical Specification

### Design & Manufacturing Standard

BS 6440:2011; EN 81-41 (Ref. only) Machine Directive 2006/42/EC

### Through Entry Configuration

Platform Size	External Lift Dimensions
800 x 1400 - Standard	980 x 1810
900 x 1400	1080 x 1810
1100 x 1400	1280 x 1810

### Bridging Steps Configuration

Platform Size	
800 x 1400 + 1 Step	980 x 1990
800 x 1400 + 2 Steps	980 x 2240
800 x 1400 + 3 Steps	980 x 2490

### Pit Mounted Configuration

Platform Size	
800 x 1400 - Standard	980 x 1555
900 x 1400	1080 x 1555
1100 x 1400	1280 x 1555




*All measurements in millimetres (mm) and provided width by length.*

*External dimensions incorporate an on-board ramp. Footprint length is 80mm longer for the standard fixed ramp at lower level.*

*There is no ramp requirement with the Pit Mounted Configuration.*



The comprehensive ranges from Pollock Lifts

	 Public Access	 At Home	 Service & Goods
Classic 1m Steplift	✓	✓	
Executive 1m Steplift	✓	✓	
Independence 2m / 3m Steplift	✓	✓	
Incline Platform Lift	✓	✓	
Vertical Platform Lift	✓		
Eco Through Floor Lift		✓	
Residential Elevator		✓	
Residential Stair Lift		✓	
Service Lift			✓
Goods Lift			✓
Dumb Waiter			✓

Find out more at [pollocklifts.co.uk](http://pollocklifts.co.uk)

➤ [Get in touch for more information](#)

1 Sloefield Drive | Trooperslane Industrial Estate | Carrickfergus | Co. Antrim | BT38 8GX | UK  
T 028 9336 8167 | E [info@pollocklifts.co.uk](mailto:info@pollocklifts.co.uk) | [www.pollocklifts.co.uk](http://www.pollocklifts.co.uk)