



A functional and stylish lift to compliment any modern space



- 280kg capacity *
- > up to 1m travel
- access between 2 levels
- user plus attendant
- wheelchair or ambulant
- internal & external
- public access

The uber stylish Executive 1m Steplift will compliment any environment, with a wide range of versatile options that enhance its ability to blend into almost any location.

The Executive is simple to operate and offers safe, easy and reliable access for wheelchair users. It also boasts a range of bespoke options that is truly unique to the access market.

The hydraulic drive, scissor-frame platform, capable of lifting up to 280kg, moves quietly between levels up to 1 metre and is suitable for both internal and external environments. And as with all Pollock Lifts, the Executive has exceptional safety standards, exceeding requirements in many areas.

Key features that elevate this stylish solution include its elegant curved profile and enhanced user experience with optional powered upper and lower gates, autodialler and auto-closers.

12 Months Warranty

Our Executive 1m Steplift comes with 12 months Parts and Labour as standard. We also offer Extended Warranties up to 5 years covering you for all service and maintenance costs.



raising expectations with the most advanced technology







Above from left to right:

Through Entry configuration with on-board ramp

Adjacent Entry configuration with fixed ramp at lower level

Pit Mounted configuration

Style that lasts

The Executive is designed to be as robust as it is stylish, and is therefore an ideal option for both internal and external public spaces. With the pump unit integrated within the lift it offers **reduced vandalism risk** and no need for a separate control unit location.

Taking only **one day to install** with **minimal builders work**, the lift can also be **relocated** offering great flexibility for the future.

Low maintenance requirements and **easy access to the pump** for servicing means your Executive 1m Steplift will provide reliable and efficient access for many years to come.

Why choose Pollock Lifts?

We have been specialising in lift access since 1983 and really understand our customers' needs and concerns.

When mobility access is required it raises many important questions and practical issues that our team are experts at solving. And our highly trained support team are here 24 hours a day to respond to your needs, wherever you are located.

As leaders in state-of-the-art lift technology, our versatile range of access solutions are designed to be elegant and fit easily into your environment, freeing up space and ensuring the ultimate in comfort and safety for its users.

"The Steplift
recommended by
Pollock Lifts was perfect.
And the wide range
of options meant it fits
in with our decor - which
is fantastic!"







Standard Features

Compact design

Stylish protective bellows - rigid and durable Aluminium checker plate flooring Simple to use

Lower fixed ramp

Easy to use emergency lowering system Improved IP 67 rated switching (waterproof)

Integrated pump unit

Reduced vandalism risk

No separate control or pump location

Easy installation and service access

1 day installation - minimal builders work Low maintenance with easy access Can be relocated

Optional Features

Gate

Automatic upper and/or lower gate(s) *
On board ramp
Gate closer

Controls

Full braille controls

Autodialler

Alarm

Keyswitch

Isolation switch

Remote controls

Full controls at serviced floors

Stainless steel call post

Choose from:

Configurations
Through Entry
Adjacent Entry
Pit Mounted (no ramp)

Platform Sizes
800 x 1400mm
900 x 1400mm
1100 x 1400mm

Finish Options

Silicon acrylic clear infill panels
Aluminium infill panels

Custom colour

Handrails

Coloured safety flooring

Flush mounted stainless steel call stations



Bespoke Option

We can create a Steplift that is bespoke to your needs. We will assist with site requirements and advise on regulations and legislation. We will ensure that your lift not only performs exactly as you want, but also looks exactly how you need it to.

Exceptional safety and load capacity unique* to Pollock Lifts



Technical Specification

Design & Manufacturing Standard

BS 6440:2011; Machine Directive 2006/42/EC

Through Entry Configuration

Platform Size	External Dimensions	Lift with Lower Gate Open	
800 x 1400 - Standard	980 x 1800	980 x 2450	
900 x 1400	1080 x 1800	1080 x 2550	
1100 x 1400	1280 x 1800	1280 x 2750	

Adjacent Entry Configuration

Platform Size		
1100 x 1400	1280 x 1760	2640 x 1760

Pit Mounted Configuration

Platform Size				
980 x 1555	980 x 2455			
1080 x 1555	1080 x 2555			
1280 x 1555	1280 x 2755			
1280 x 1445	2640 x 1445			
	1080 x 1555 1280 x 1555	1080 x 1555 1080 x 2555 1280 x 1555 1280 x 2755		

All measurements in millimetres (mm) and provided width by length.

External dimensions incorporate an on-board ramp. Footprint length is 80mm longer for the standard fixed ramp at lower level. There is no ramp requirement with the Pit Mounted Configuration.



The comprehensive ranges from Pollock Lifts

	& Public Access	At Home	Service & Goods
Classic 1m Steplift			
Executive 1m Steplift			
Independence 2m / 3m Steplift	\checkmark	\checkmark	
Incline Platform Lift	\checkmark	\checkmark	
Vertical Platform Lift			
Eco Through Floor Lift			
Residential Elevator		\checkmark	
Residential Stair Lift			
Service Lift			
Goods Lift			\checkmark
Dumb Waiter			

Find out more at pollocklifts.co.uk

> Get in touch for more information

1 Sloefield Drive | Trooperslane Industrial Estate | Carrickfergus | Co. Antrim | BT38 8GX | UK T 028 9336 8167 | E info@pollocklifts.co.uk | www.pollocklifts.co.uk